



PULLDOWN SCREEN INSTALLATION WITH MAGNETS

SportScreen Installation Instructions

Tools Required

1. Drill + drill index
2. Level (2–4 ft recommended)
3. Tape measure
4. #2 Phillips screwdriver
5. Ladder
6. Pencil/marker

Step 1: Determine where the rails will be mounted

1. Measure height (floor to header) on both sides and deduct (3” inches). To allow for the housing sitting on top of the rail.
2. Transfer the dimension to the rail for cutting. Cut off the excess from the open end of the rails.
3. Predrill the flange on both rails with a (3/16” inch drill bit) 18” inches apart.
4. Install the left side rail.

Step 2: Install the Housing (Canister)

1. Install the left side housing cap tab into the top of the left rail that was installed.
2. Lift canister and install the right rail under the housing cap tab.

Step 3: Fasten the housing and rails

1. Secure the housing with screws using the tab inside of the rail with predrilled holes.
2. Finish fastening the rails.

Step 5: Cleaning

1. Make sure to remove any shavings from the magnets.
2. Clean the strike plate surface inside the bottom of the rail.

Step 4: Feed the Screen into the Tracks

1. Slowly pull the screen down from the housing.
2. Guide both edges into the side rails.
3. Make sure:
 - The screen is evenly seated on both sides
 - It slides freely without catching

Step 7: Latching trouble

1. If the unit does not stay latched or releases easily.
 - Make sure nothing is holding up the magnet from the strike plate.
 - Back the turns off the screw that mounts the magnet by 1 or 2 turns to allow it to pivot.